

S Sandberg®
ACTIVE 

Outdoor Solar Powerbank 16000




Quick guide

420-35




www.sandberg.world

Charge Powerbank




Battery mAh	Battery Watt-hours	Solar panel Watt	Charging time by sun	Charging time by USB 1A	Charging time by USB 2.4A	Charging time by USB C 18W
16000	59.2 Wh	1.4W	51 hours	13 hours	5 hours	4 hours

Charge devices



Charge one smartphone and one tablet or two smartphones by USB-A.



Or charge one smartphone or one tablet by USB-C.

Flashlight procedure



Press once to 100% brightness



Press again to 25% brightness



Press once again to strobe



Press once to turn off LED light



Hold about 3 seconds for SOS



Support

<http://helpdesk.sandberg.world>

Warranty

There is a five-year warranty on your Sandberg product. Please read the warranty terms and register your new Sandberg product at www.sandberg.world/warranty

5
Years
Warranty

For information on handling electronic waste, see www.sandberg.world/weee



WEEE